

## Pressure Switch Fitting Instructions



### Kit Reference Numbers

- AQU-PSW-040 – For DP4 & DP5 - Models with pressure switches set lower than 60 psi
- AQU-PSW-100 – For DP4 & DP5 - Models with pressure switches set between 60 – 130 psi

Remove wires from connectors, remove 4 x screw, remove old switch.

Take care when fitting the new switch in case it comes apart as there several parts, see left picture below. Position on pump, see right picture below.

Fit screws ensuring the screws are tightened to prevent leakage.

To set to the desired shut off pressure use a pressure gauge on the outlet side of the pump and adjust using the small 1/16" grubscrew on top of the pressure switch.

